

# Paraprimer™

## Substrate Primer

## Specification Data

### Product Description:

Paraprimer™ is a bonding agent for use with pressure sensitive Paramount waterproofing materials such as Parastick 'n' Dry, Superstop and various tapes.

### Basic Uses:

Paraprimer is an adhesive primer formulated to prepare construction surfaces prior to application of Parastick 'n' Dry, Superstop and various tapes. Construction surfaces other than the HDPE liner are always primed with Paraprimer prior to taping. Paraprimer helps create a bonding to any sound, clean surface and to provide a flexible base to enhance adhesion.

### General:

Always cover Paramastic with a protective layer of Paraseal membrane. All vertical inside corners receive a cove detail of Paramastic.

### Penetrations:

Place 1" cove around all penetrations and extend 1.5" beyond.

### Lagging:

Apply Paramastic around all tie-backs and penetrations. Protect with 4 mil polyethylene or a protective layer of Paraseal LG.

### INSTALLATION:

#### Preparatory Work:

Surfaces must be sound and free of contaminants.

#### Directions:

Metal I-Beams (soldier pile)

- a. Scrape loose dirt and rust from an area at least one inch larger than the area to be covered.
- b. With brush, spray or roller, evenly spread a coating over the entire area. Work Paraprimer into crevices and irregularities.

### TECHNICAL DATA

Flammability . . . . .	Yes
Weight . . . . .	7.2 lbs. per gallon
Viscosity . . . . .	70-120 CP
Percent nonvolatile . . . . .	approx. 55%
Approximate coverage per gallon:	
Metal . . . . .	150-300 sq ft per gallon
Concrete . . . . .	100-300 sq ft per gallon
Wood . . . . .	100-300 sq ft per gallon
Shipping Weight:	
1 gallon pail . . . . .	8.0 pounds

c. Allow to dry until tacky to the touch — time required depends directly on the temperature, humidity and thickness of the Paraprimer.

d. After drying, firmly press Parastick 'n' Dry into the primed surface.

#### Clean-up:

Immediately use absorbent or squeegee into appropriate container. If set up, use mineral spirits or paint thinner.

#### Caution:

Do not install Paraprimer during inclement weather. Do not install where substrate or air is at, or will drop below 10°F within two hours. Follow all precautionary information stated in the "Material Safety Data Sheet" and on the label. Do not breathe spray, or use without protective eyewear.

#### Limitations:

Surfaces must be clean and dry. No frost or foreign substances which could interfere with adhesive bonding.

#### AVAILABILITY:

Paraprimer is available throughout the United States. Contact the manufacturer for your nearest supplier.

#### WARRANTY

MAMECO warrants its Paraseal products to be free of defects in any materials, but makes no warranty as to appearance or color. Since methods of application can affect performance, MAMECO makes no other warranty, express or implied, including warranties of MERCHANTABILITY and FITNESS FOR A PARTICULAR PURPOSE, with respect to Paraseal products. MAMECO's sole obligation shall be, at its option, to replace or to refund the purchase price of the quantity of Paraseal product proved to be defective and MAMECO shall not be liable for any loss or damage including incidental or consequential damages arising from the use of Paraseal products.

# FABRIKEM

## MANUFACTURING LTD.

20361 Duncan Way, Langley, B.C. V3A 7N3  
Telephone: (604) 532-3883 Facsimile: (604) 532-3164  
Toll Free Telephone: (800) 441-7456  
Website: [www.fabrikem.com](http://www.fabrikem.com)  
Email: [info@fabrikem.com](mailto:info@fabrikem.com)